

REMOTE VIEW PRO

UPS & STS Remote Monitoring SW

EN



EN TABLE OF CONTENTS

1. CERTIFICATE AND CONDITIONS OF WARRANTY	4
1.1. Copyright and Intellectual Property ownership rights	4
1.2. License to use	4
1.3. Entry into force and duration of the license	4
1.4. Warranty conditions	5
1.5. Software updates	5
1.6. Limitations of liability	5
1.7. Severability	5
1.8. Amendments to the License	5
1.9. Applicable law	5
2. PRESENTATION	6
2.1. REMOTE VIEW PRO in brief	6
2.2. Software functions	6
2.3. REMOTE VIEW PRO architecture	7
3. SOFTWARE COMPATIBILITY	8
3.1. Windows® versions	8
3.2. WEB browser compatibility	8
3.3. UPS Compatibility	8
3.4. SNMP interface	8
4. REQUIREMENTS	9
4.1. Computer hardware	9
4.2. IIS – MS® Internet Service	9
4.3. Admin account Rights	9
4.4. Services	9
4.5net package	9
5. SOFTWARE ARCHITECTURE	.10
5.1. Architecture overview	.10
5.2. Rules	.10
5.3. User	.11
5.4. Device management	.11
5.5. User interface	.11
5.6. RV Pro Service (Server or Client)	.11
6. WEB INTERFACE	.12
6.1. HOMEPAGE	.12
7. REMOTE VIEW PRO OPERATION	13
7.1. UPS Status window – Main menu	.13
7.2. STS Status window – Main menu.	.15
7.3. STATYS XS - Status page	.17
7.4. Device event log	.18
7.5. Device contextual menu	.20
7.6. Dashboard contextual menu	.21
7.7. Entire view	.21
7.8. Logs Menu	.22

8. UPS EVENTS MANAGEMENT	26
8.1. New incoming UPS event	26
8.2. Popup windows	26
8.3. Event Acknowledgement	27
9. INSTALLATION	28
9.1. Server installation by default	28
9.2. Client installation	30
9.3. Administrator login page	30
10. REMOTE VIEW PRO SETUP STEP BY STEP	31
10.1. Admin account login	31
10.2. Company creation	31
10.3. User creation	32
10.4. Device Group creation	33
10.5. Adding new User or Device	42
11. E-MAIL NOTIFICATION	43
11.1. SMTP Configuration	43
11.2. Test e-mail:	43
11.3. E-mail notification settings	44
12. SYSTEM PARAMETERS	45
12. SYSTEM PARAMETERS 12.1. Menu System	45 45
12. SYSTEM PARAMETERS 12.1. Menu System 12.2. License management	45 45 45
12. SYSTEM PARAMETERS 12.1. Menu System 12.2. License management 12.3. About	45 45 45 45
12. SYSTEM PARAMETERS 12.1. Menu System 12.2. License management 12.3. About 13. ADDING RV PRO CLIENT FROM REMOTE COMPUTER	45 45 45 45 46
12. SYSTEM PARAMETERS 12.1. Menu System 12.2. License management 12.3. About 13. ADDING RV PRO CLIENT FROM REMOTE COMPUTER. 13.1. Local machine settings	45 45 45 45 45 46 46
12. SYSTEM PARAMETERS 12.1. Menu System 12.2. License management 12.3. About 13. ADDING RV PRO CLIENT FROM REMOTE COMPUTER. 13.1. Local machine settings 13.2. Create the RV PRO service in Server.	45 45 45 45 46 46 46
12. SYSTEM PARAMETERS 12.1. Menu System 12.2. License management 12.3. About 13. ADDING RV PRO CLIENT FROM REMOTE COMPUTER 13.1. Local machine settings 13.2. Create the RV PRO service in Server 13.3. Case of different companies, sites or locations	45 45 45 46 46 46 46
12. SYSTEM PARAMETERS 12.1. Menu System 12.2. License management 12.3. About 13. ADDING RV PRO CLIENT FROM REMOTE COMPUTER. 13.1. Local machine settings 13.2. Create the RV PRO service in Server. 13.3. Case of different companies, sites or locations 14. TRAP LIST.	45 45 45 46 46 46 47 48
 12. SYSTEM PARAMETERS	45 45 45 46 46 46 46 47 48 48
 12. SYSTEM PARAMETERS 12.1. Menu System 12.2. License management 12.3. About 13. ADDING RV PRO CLIENT FROM REMOTE COMPUTER. 13.1. Local machine settings 13.2. Create the RV PRO service in Server. 13.3. Case of different companies, sites or locations 14. TRAP LIST. 14.1. NET VISION 6 MIB FILE 14.2. RFC 1628 	45 45 45 46 46 46 46 47 48 48 48
 12. SYSTEM PARAMETERS 12.1. Menu System 12.2. License management 12.3. About 13. ADDING RV PRO CLIENT FROM REMOTE COMPUTER. 13.1. Local machine settings 13.2. Create the RV PRO service in Server. 13.3. Case of different companies, sites or locations 14. TRAP LIST. 14.1. NET VISION 6 MIB FILE 14.2. RFC 1628 14.3. NETVISION 7 TRAP LIST. 	45 45 46 46 46 46 47 48 48 49 49 49
12. SYSTEM PARAMETERS 12.1. Menu System 12.2. License management 12.3. About 13. ADDING RV PRO CLIENT FROM REMOTE COMPUTER. 13.1. Local machine settings 13.2. Create the RV PRO service in Server. 13.3. Case of different companies, sites or locations 14. TRAP LIST. 14.1. NET VISION 6 MIB FILE 14.2. RFC 1628 14.3. NETVISION 7 TRAP LIST. 14.4. STS TRAP LIST.	45 45 45 46 46 46 46 46 48 48 49 49 49 49
 12. SYSTEM PARAMETERS	45 45 46 46 46 46 46 47 48 48 49 49 49 49 49 49
 12. SYSTEM PARAMETERS	45 45 45 46 46 46 46 47 48 49 49 49 49 49 49 49 49 50
 12. SYSTEM PARAMETERS	45 45 46 46 46 46 46 47 48 48 49 49 49 49 49 49 49 50 51
 12. SYSTEM PARAMETERS	45 45 46 46 46 46 46 47 48 49 49 49 49 49 49 49 50 51 51

1. CERTIFICATE AND CONDITIONS OF WARRANTY

Installing the software means full acceptance of all contractual terms. For this reason, please read all the points listed below carefully.

If you do not agree with any of the contractual terms, do not install the software and/or return it immediately to SOCOMEC.

1.1. COPYRIGHT AND INTELLECTUAL PROPERTY OWNERSHIP RIGHTS

The user of the software acknowledges that all rights referred to and the copyright belong exclusively to SOCOMEC, in relation to both the source code and the object code.

Anyone entering into possession of the software without prior authorization from SOCOMEC must immediately uninstall it, if it has been installed, and return it to SOCOMEC. If such persons fail to take this action SOCOMEC will exercise its rights to the full extent permitted by civil and criminal law.

The software and documentation are protected by copyright. The unlawful use and/or partially or totally copying of the software shall lead to claims for damages. However, you are allowed to create a back-up copy of the media supplied by SOCOMEC (CD Rom).

This documentation and software are not specifications. SOCOMEC reserves the right to make changes to information without prior notice.

SOCOMEC retains the full and exclusive ownership of all intellectual rights, such as, but not limited to those relating to documentation, software, source code, object code etc. Only a personal entitlement to use the documentation and software for the application indicated by SOCOMEC is granted to the recipients. The reproduction, modification, or distribution of this documentation and software either partially or totally and in any way is expressly prohibited except upon Socomec's express prior written consent.

1.2. LICENSE TO USE

The *REMOTE VIEW PRO* software (object code) and supporting documentation are freely installable for private use solely in combination with the use of SOCOMEC's products.

The software contains confidential information. This license does not authorize the user to modify, adapt, decompile, or disassemble the software in question or to reconstruct the source code using any other method. SOCOMEC will protect its rights against any such unauthorized use to the full extent permitted by civil and criminal law.

The software may not be hired out to third parties. The license of use for this software is issued exclusively for the purposes laid out in the software documentation.

1.3. ENTRY INTO FORCE AND DURATION OF THE LICENSE

This license enters into force on the day of installation of the software, whereby the user accepts these conditions of use and liability. The license is open term and has no date of expiry. The License and the limited rights of use by the user of the software will be invalidated in the event of a breach of any of the points outlined in paragraphs 1.1. "Copyright and Intellectual Property ownership rights" and 1.2. "License to use".



1.4. WARRANTY CONDITIONS

SOCOMEC neither implicitly nor explicitly provides any warranty concerning the usability of the software. Despite the extensive use of resources to develop the software, no guarantees are provided concerning the absence of errors. SOCOMEC may provide the support needed to solve any errors present in the software. Such support is limited to the correction of programming errors and is not extended to the implementation of new functions that are not present in the version of the software installed by the user. If the user finds any manifest or hidden errors, SOCOMEC should be notified of such errors in writing.

1.5. SOFTWARE UPDATES

This License does not grant the right to receive software updates, or new versions.

1.6. LIMITATIONS OF LIABILITY

SOCOMEC shall not be held liable, under any circumstances, for damage of any kind, including economic damage, directly or indirectly consequential to the use of, or inability to use the software.

1.7. SEVERABILITY

If any clause of this contract is found to be ineffective or becomes ineffective for any reason whatsoever, the remaining terms of the License shall still apply. The unenforceable clause or ineffective provisions will be replaced by a clause, also with retroactive effect, that addresses subsequently identified requirements, within the scope of legal enforceability.

1.8. AMENDMENTS TO THE LICENSE

Any amendment to this License must be made in writing.

1.9. Applicable law

This contract is subject to French law.

The information contained herein, the software and documentation, are the exclusive property of SOCOMEC.

SOCOMEC retains the full and exclusive ownership rights over this document. Only a personal right to utilize the document for the application indicated by SOCOMEC is granted to the recipient of such document. All reproduction, modification or dissemination of this document whether in part or whole and by any manner are expressly prohibited except upon Socomec's express prior written consent.

This document is not a specification. SOCOMEC reserves the right to make any changes to data without prior notice.

2. PRESENTATION

2.1. REMOTE VIEW PRO IN BRIEF

- *REMOTE VIEW PRO* is a software programme for the remote monitoring of UPS and STS equipment, like a "Network Management Station" (NMS) dedicated to UPS and STS.
- *REMOTE VIEW PRO* is web based software allowing the monitoring of UPS and STS from every computer connected to the same network, LAN or WAN architecture, using a web browser.
- All UPS having Ethernet connection and SNMP protocol can be monitored with this software.
- *REMOTE VIEW PRO* includes SOCOMEC's NET VISION MIB files, and also standard RFC1628 UPS MIB file, compliant with almost any UPS manufacturer (APC / EATON / EMMERSON, etc.).

2.2. SOFTWARE FUNCTIONS

Functions	Description	Using NET VISION MIB file
UPS monitoring	Battery status Load status	
UPS parameter trends	Output load rate Output voltage Battery voltage Input voltage Input frequency Battery capacity UPS temperature	EMD Temperature EMD Humidity
STS monitoring	Source 1 and 2 status Load status	
STS parameters trends	Output load rate Output voltage Input source 1 and 2 voltage Input source 1 and 2 frequency	
TRAP notification	Via E-mail Via SMS (needs external GSM modem) Via popup windows Via buzzer	TRAP follows the well- KnownAlarm list described in the MIB file. It includes also TRAP coming for EMD if con- nected to NET VISION
Event log file	Filters can be applied by company / device / time window Export in CSV format	
History log file	Filters can be applied by company / device / time window Measurements table records and graphs Export in CSV format	
User Dashboard	It includes maps or pictures, where the UPS and STS are monitored. Defines the interface when user is logged on	
Event level management	UPS's and STS's icon changes colour depend- ing on the level of event: Info / Warning / Critical	
Reporting	Critical / Warning / Info event counters	
UPS discovery	Displays the list of all UPS recognized on network	Function only available with NET VISION Card
WEB/SNMP Card remote configuration	The SNMP TRAP table is set with the IP ad- dress of RV PRO server	
Multi users access	Super-admin account User with admin role User with user role	
User login	Protected by verification code	

2.3.1. LAN architecture

All UPS are in a same network and same domain - Remote View Pro server installation



2.3.2. WAN architecture



Case of different LAN - Remote view Pro client has to be setup in addition of Remote View Pro Server

SERVER	It includes all services needed for UPS and STS monitoring		
RV PRO Server	This service manages the SNMP communication with all UPS and STS connected to this service		
DATA BASE	Manages all data, such as events log and measurements collected from all RV PRO services		
WWW service	Web server used for user interface		
CLIENT	Remote station connected to a different LAN		
RV PRO Client	This service collects data from all UPS and STS connected to this local network, and push data to Remote View Pro Server		

2.3.3. Definition

3. SOFTWARE COMPATIBILITY

3.1. WINDOWS® VERSIONS

APPLICATION	WINDOWS® VERSIONS	RAM / DISK	COMMENTS
SERVER INSTALLATION	7 / 10 2008 R2 2012 R2 2016 - 2019	16 / 64Gb	It is recommended to use Win- dows® Server version, as this pro- gramme should always be running ir
CLIENT INSTALLATION	7 / 8 / 10 2008 R2 2012 R2 2016 - 2019	8 / 32Gb	order to have a reliable and efficient UPS and STS monitoring system. Can also run on VM

3.2. WEB BROWSER COMPATIBILITY

EDGE	starting v 91
Chrome	22 or above
Safari	9 or above
Firefox	15 or above

3.3. UPS COMPATIBILITY

UPS RANGE		ETHERNET CARD	MIB FILE
	NETYS PR RT	NET-VISION	NET-VISION
	NETYS 1,1 – 3kVA	RT-VISION	RFC1628
	NETYS 5 – 11 kVA	Embedded Card	RFC1628
\bigcirc	ITYS all ranges	NET-VISION	NET-VISION
	MODULYS	NET-VISION	NET-VISION
Ō	MODULYS GP 2.0	NET-VISION	NET-VISION
	MASTERYS all ranges	NET-VISION	NET-VISION
S S	DELPHYS all ranges	NET-VISION	NET-VISION
	Futures UPS ranges	NET-VISION	NET-VISION
	STATYS XS	STATYS XS WEB/ SNMP CARD	ATS MIB FILE
	STATYS range	Embedded RJ45	STS MIB FILE
Other UPS manufacturers		WEB/SNMP option Card	RFC1628

REMOTE VIEW PRO distinguishes between NET VISION 5 and NET VISION 6.

3.4. SNMP INTERFACE

RV PRO SERVICE	v1	v2c	v3
NET VISION 7	Doesn't use SNMP protocol		
NET VISION 5 or 6	YES	-	YES
RT VISION	YES	-	YES
RT Embedded Card	YES	-	YES
Other uses RFC1628	YES	YES	YES
STATYS XS	YES	YES	YES
STATYS	YES	-	-

4. REQUIREMENTS

4.1. COMPUTER HARDWARE

- Physical or VM machine
- Minimum disk space: 64 GB
- Network connection
- SNMP ports open
- HTTP port: 80 by default
- Network bandwidth: depends on number of UPS to monitor, and data polling rate (getsnmp), set at 5s by default
- Internet connection (Google map and Baidu map access)

4.2. IIS – MS® INTERNET SERVICE

Before installing *REMOTE VIEW PRO*, you need to install Internet Service (IIS) native on Windows®. *REMOTE VIEW PRO* will be installed in C:\Inetpub\wwwroot folder.

4.3. Admin account Rights

To install REMOTE VIEW PRO, you need to have administrator rights account.

4.4. SERVICES

4.4.1. RV Pro Service

This service is installed during *REMOTE VIEW PRO* setup. This service starts automatically at the end of the installation.

RV PRO service status	Systray icon
Running	
Disconnected	
Service stopped	lcon not present

4.4.2. MySql service (MySqlCloudEx0)

This service manages the data base. MySql is bundled with *REMOTE VIEW PRO* installation package. This service starts automatically at the end of the installation.

4.4.3. WWW service

This service starts automatically after IIS installation. This service has to be running before installing *REMOTE VIEW PRO*.

4.5. .NET PACKAGE

ASP.NET 4.5 .NET 3.5 package

5. SOFTWARE ARCHITECTURE

REMOTE VIEW PRO manages hierarchic structure. The structure begins from "root-company". From this point it is possible to create several companies, such as different networks, different locations, different sites etc., according to the real architecture to monitor.

For each "company" node, a list of users and a list of devices are created.



5.1. ARCHITECTURE OVERVIEW

5.2. RULES

- Users are linked to company
- Users cannot see devices from other companies

5.3. USER

- Each user has its own account
- The dashboard (user interface) defined at user level includes:
 - o Maps, drawings or photos
 - o All UPS and STS managed by the user over the maps or picture.
 - o The User can define a second level, adding a new view of devices

Function	Super-user / Admin	User with admin role	User with user role
User account type		ø	9
Company creation	YES	NO	NO
Add new user	YES in all companies	YES for their company	NO
Adding device group	YES	YES for their company	NO
Adding / removing device	YES	YES for their company	NO
Modifying maps / pictures	YES	YES for their Group	NO
Browsing device	YES	YES	NO
Editing Report	For all devices	For all devices for their company	NO
E-mail setting notification	YES	NO	NO
System configuration	YES	NO	NO

5.4. DEVICE MANAGEMENT

- Device group includes all RV Pro Service (Server or Client).
- For each RV Pro Service, you need to add UPS managed by this service

5.5. USER INTERFACE

- A graphical interface is defined for each user.
- The background picture or map is set at user level.
- All devices managed by this user can be added over the picture or map

5.6. RV PRO SERVICE (SERVER OR CLIENT)

- 5.6.1. Functions:
 - o collects data from UPS through SNMP
 - o displays the popup window when a new TRAP is received

5.6.2. Configuration

- o enable / disable popup windows
- o polling rate

Configuration		
GUID:	9B30DDEC-A353-4637-8C1B-	2163330130FB
Server IP:	172 . 23 . 27 . 168	
Port:	80]
Password:	•••••	
Polling Rate:	10	(3 \sim 30 Seconds
[Popup Event Notification	
[ОК	Cancel

6. WEB INTERFACE

6.1. HOMEPAGE

🗅 REMOTE VIEW PRO - 🗙		
← → C 🗋 localhost/cloud/public/index/index	ex	? ☆ =
REMOTE VIEW PRO		
Main Logs Report Notifica	tion System 🔰 🚺	📕 🐟 🛔 🔍 🛕 🔍 🏓 🎓 🗲
E Root-Company	Map Company List	English 🔻
×	Company Name Telephone Address	FAX Web Business Tax ID Description
4	5	
	₩ page 1 of 1 ₩	Display 1 - 1 of 1 🗸
2015 All Rights Reserved	_	

		Main	Access to tree architecture and user interface area			
			Calendar	Day per day		
		Logs	History Log	Measurements		
			Device event Log	TRAP log		
1	MENU		System event Log			
		Report		Event statistics		
		Netification	E-mail / SMPT settings	Cupor odmin only		
		Notification	SMS / Modem settings	Super-admin only		
		System	RV PRO configuration	Super-admin only		
2	Last events rotator	Display last events trigged				
		Events accumulation icons	Counter of Critical / Warning / Info triggered during the session	Shortcut to event log		
3	Shortcut icons	User login 🍶 灥 🔗	Change password			
		Help	About	Register •		
		Logout 💉	Close the session			
4	Tree architecture area	List of companies, users and devices				
5	User interface area	Dashboard / configuration page / history logs				

7. REMOTE VIEW PRO OPERATION

7.1. UPS STATUS WINDOW - MAIN MENU



Selection of the device in the tree, or

double click of the UPS icon in the dashboard

7.1.1. UPS Status

LOAD S	STATUS	BATTERY STATUS			
NET VISION	RFC1628	NET VISION	RFC1628		
Unknown	Other	Unknown	Unknown		
onInverter	None	batteryNormal	batteryNormal		
onMains	Normal	batteryLow	batteryLow		
ecoMode	Bypass	batteryDepleted	batteryDepleted		
onBypass	Battery	batteryDischarging			
Standby	Booster	batteryFailure			
onMaintenanceBypass	reducer	batteryDisconnected			
upsOff					
normalMode					

7.1.2. UPS Status Shortcuts

12 Device Event Log

History log: measurements log

Browse device: open web interface in separate window

7.1.3. UPS Parameters



The updating rate is fixed according the polling rate set in the RV Pro server.

List of measurements:

- Input voltage
- Output voltage
- Input frequency
- Output load
- Output load by phase for Net Vision 7
- Battery capacity
- Battery voltage
- UPS temperature
- EMD temperature (only with NET VISION)
- EMD humidity (only with NET VISION)

7.2. STS STATUS WINDOW - MAIN MENU



Selection of the device in the tree, or

double click of the UPS icon in the dashboard

7.2.1. STS Status Page



7.2.2. STS Status Data

STS Output Status

- Unknown
- On preferred Source
- On alternate Source
- Output Off
- On maintenance BP1
- On maintenance BP2

STS Source 1and 2 Status

- Unknown
- OK
- Critical
- Out of tolerances
- Absent

STS Source 1 Preferred

- No
- Yes

List of measurements:

- Input Source 1 and 2 voltage
- Output voltage
- Input Source 1 and 2 frequency
- Output load

The updating rate is link to polling rate set on Remote View pro service or specify for Net Vision 7 in Remote View Pro.

7.2.3. STS Status Shortcuts



12 Device Event Log



Browse device: open web interface in separate window



7.3. STATYS XS - STATUS PAGE

and the second		
ATS Status		
Output Source : Source B Input Preference : Source B Source A Status : OK Source B Status : OK		团 O @
	A	_
	H	·
		⊨→≣
	\$ >	~~ ≣
	В	
	incut A selfman (v/	Loost A Biologous (Art)
250	input a votrage (v)	250
200		200
150		120
100		100
50		
190 50 0	235 (V)	50 (Hz)
500 50 0	235 (V)	1 50 (Hz)
50 50 0	235 (V)	50 (Hz)
100 58 0	235 (V)	50 (Hz)
990 50 0	235 (V) Injuni 8 veitage (V)	50 (Hz)
220 20 20 20	2.35 (V) Input 8 veltage (V)	10 50 (Hz)
100 10 12 200 00	235 (V) separat sellage (v)	50 (Hz)
200 200 200 200 300 300 300	235 (V) mput it validate (V)	50 (Hz)
	235 (V) Hope & Mitage (V)	50 (Hz)

7.3.1. STS Status Data

ATS - STATYS XS Output Status

- On Source A
- On Source B
- Output Off
- On Bypass A (*)
- On Bypass B (*)

Input Preference: ATS Select / Source A / Source B (Symbol 🔷)

Remark in case of Input Preference A or B:

If the switch back delay is shorter as the RV Pro polling rate, the sources changing will not appears on the synoptic.

STS Source 1 and 2 Status

- OK
- Fail

List of measurements:

- Input Source A and B voltage
- Output voltage
- Input Source A and B frequency
- Output load rate / Current
- internal temperature

The updating rate is link to polling rate set on Remote View pro service.

(*) only for STATYS XS E 32A serie

7.3.2. ATS - STATYS XS Shortcut



12 Device Event Log

History log: measurements log

Browse device: open web interface in separate window

7.4. DEVICE EVENT LOG

Î

12	This shortcut opens the <u>Device Event Log</u> page	, with the selected device in the filter field
----	--	--

From: 2016/02/12				2 To:	2016/02/12	12
Company:	Company			Device:	BOX Emulator	· · · · · · · · · · · · · · · · · · ·
Severity:	All		Search:			
Ack:	Ack: All			-		
						Apply
Prev Pag Device Ever	e Next Page					
Prev Pag Device Ever Acknowledg	ge Next Page at Logs P Date	Time	Company	Device	Severity	Event Description
Prev Pag Device Ever Acknowledge	e Next Page at Logs Date 2016/02/12	Time 11:07:53	Company	Device BOX Emulator	Severity	Event Description
Prev Pag	Date 2016/02/12 2016/02/12	Time 11:07:53 11:07:32	Company Company Company	Device BOX Emulator BOX Emulator	Severity information warning	Event Description Load supplied by bypass A general fault in the UPS has been detected.
Prev Pag Device Ever	e Next Page it Logs Date 2016/02/12 2016/02/12 2016/02/12	Time 11:07:53 11:07:32 11:07:31	Company Company Company Company	Device BOX Emulator BOX Emulator BOX Emulator	Severity information warning warning	Event Description Load supplied by bypass A general fault in the UPS has been detected. UPS temperature is out of tolerance.
Prev Pag	e Next Page it Logs Date 2016/02/12 2016/02/12 2016/02/12 2016/02/12	Time 11:07:53 11:07:32 11:07:31 10:45:01	Company Company Company Company Company	Device BOX Emulator BOX Emulator BOX Emulator BOX Emulator	Severity information warning warning information	Event Description Load supplied by bypass A general fault in the UPS has been detected. UPS temperature is out of tolerance. Removed: A problem has been encountered in the communications between the
Prev Pag Device Ever Acknowledge	e Next Page tt Logs Date 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12	Time 11:07:53 11:07:32 11:07:31 10:45:01 10:44:53	Company Company Company Company Company	Device ROX Emulator ROX Emulator ROX Emulator BOX Emulator ROX Emulator	Severity information warning warning information information	Event Description Load supplied by bypass A general fault in the UPS has been detected. UPS temperature is out of tolerance. Removed: A problem has been encountered in the communications between the A problem has been encountered in the communications between the agent and
Prev Pag	Next Page Next Page Date 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12	Time 11:07:53 11:07:32 11:07:31 10:45:01 10:44:53 10:14:20	Company Company Company Company Company Company Company	Device BOX Emulator BOX Emulator BOX Emulator BOX Emulator BOX Emulator BOX Emulator	Severity information warning information information information	Event Description Load supplied by bypass A general fault in the UPS has been detected. UPS temperature is out of tolerance. Removed: A problem has been encountered in the communications between the A problem has been encountered in the communications between the agent and Removed: The remaining battery run-time is less than or equal to battery low to
Prev Pag	Next Page Date 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12 2016/02/12	Time 11:07:53 11:07:32 11:07:31 10:45:01 10:44:53 10:14:20 09:32:21	Company Company Company Company Company Company Company Company	Device BOX Emulator BOX Emulator BOX Emulator BOX Emulator BOX Emulator BOX Emulator	Severity information warning warning information information information connect	Event Description Load supplied by bypass A general fault in the UPS has been detected. UPS temperature is out of tolerance. Removed: A problem has been encountered in the communications between the A problem has been encountered in the communications between the agent and Removed: The remaining battery run-time is less than or equal to battery low to The device is connected

This page allows acknowledgement of new incoming events.

The Device name hypertext opens the device web page

7.4.1. UPS and STS History Log

S This shortcut opens the <u>Device History Log</u> page, with the selected device in the filter field.

History Log						
Company: End Date:	Company 2016/02/12	•	Device: End Time:	MODULYS GP 2.0 11:33	v	
Time unit:	Raw data	Ť	Time window:	Ap	pply	
Prev Next						

Time window has to be chosen before displaying values table.

	Raw data	Record sample defined by polling rate in RV Pro Service. (5 to 30s)		
	Minute			
Time Unit	Hour			
	Day	Select record sample		
	Month			
	Year			
Time window	Value calculated according to Time Unit	For raw data: 20 / 40 / 60 / 120 minutes		

Example:

- Time Unit = Minute
- Time window = 1 hour

Table presentation: 6 pages of 10 records.

	Company		Ŧ	Device: MOE	OULYS GP 2.0	Ŧ			
End Date:	2016/02/12	2	12	End Time: 11:3	3				
Time unit:	Raw data		v	Time window: 20 n	nin	٣			
						Apply			
Prev	Next								
Numerical Da	ta	Graphic Data							
Date	Time	Device	IP	Input Voltage (volt)	Output Voltage (volt)	Output Load (%)	UPS Temperature (°C)	Battery Capacity (%)	
2016/02/12	11:32:07	MODULYS GP 2.0	172.23.14.31	235.0,235.3,234.5	230.0,230.0,230.0	0.0,0.0,0.0	26.3	100	
2016/02/12	11:31:05	MODULYS GP 2.0	172.23.14.31	235.0,234.0,233.8	230.0,230.0,230.0	0.0,0.0,0.0	26.0	100	
	11:30:02	MODULYS GP 2.0	172.23.14.31	235.2,234.8,234.5	230.0,230.2,230.0	0.0,0.0,0.0	26.2	100	
2016/02/12		HODILLYS CD 2 O	172.23.14.31	236.0,235.0,234.3	230.3,230.5,230.3	0.0,0.0,0.0	26.7	100	
2016/02/12 2016/02/12	11:29:00	MODULTS GP 2.0							
2016/02/12 2016/02/12 ord samp	11:29:00 le time	= 1 minute	172.23.14.31	235.8,235.2,234.6	230.0,230.2,230.2	0.0,0.0,0.0	26.0	100	
2016/02/12 2016/02/12 ord samp 2016/02/12	11:29:00 le time 11:27:07	= 1 minute MODULYS GP 2.0	172.23.14.31 172.23.14.31	235.8,235.2,234.6 235.2,235.3,234.5	230.0,230.2,230.2 230.0,230.0,230.2	0.0,0.0,0.0	26.0 26.0	100 100	
2016/02/12 2016/02/12 ord samp 2016/02/12 2016/02/12	11:29:00 le time 11:27:07 11:26:04	= 1 minute MODULYS GP 2.0 MODULYS GP 2.0	172.23.14.31 172.23.14.31 172.23.14.31	235.8,235.2,234.6 235.2,235.3,234.5 235.7,235.3,234.7	230.0,230.2,230.2 230.0,230.0,230.2 230.2,230.3,230.3	0.0,0.0,0.0 0.0,0.0,0.0 0.0,0.0,0.0	26.0 26.0 26.0	100 100 100	
2016/02/12 2016/02/12 ord samp 2016/02/12 2016/02/12 2016/02/12	11:29:00 le time 11:27:07 11:26:04 11:25:02	MODULYS GP 2.0 = 1 minute MODULYS GP 2.0 MODULYS GP 2.0 MODULYS GP 2.0	172.23.14.31 172.23.14.31 172.23.14.31 172.23.14.31	235.8,235.2,234.6 235.2,235.3,234.5 235.7,235.3,234.7 235.2,235.2,234.3	230.0,230.2,230.2 230.0,230.0,230.2 230.2,230.3,230.3 230.5,230.2,230.2	0.0,0.0,0.0 0.0,0.0,0.0 0.0,0.0,0.0 0.0,0.0,	26.0 26.0 26.0 26.2	100 100 100 100	
2016/02/12 2016/02/12 ord samp 2016/02/12 2016/02/12 2016/02/12 2016/02/12	11:29:00 le time 11:27:07 11:26:04 11:25:02 11:24:10	MODULYS GP 2.0 = 1 minute MODULYS GP 2.0 MODULYS GP 2.0 MODULYS GP 2.0 MODULYS GP 2.0	172.23.14.31 172.23.14.31 172.23.14.31 172.23.14.31 172.23.14.31 172.23.14.31	235.8,235.2,234.6 235.2,235.3,234.5 235.7,235.3,234.7 235.2,235.2,234.3 235.6,235.0,234.0	230.0,230.2,230.2 230.0,230.0,230.2 230.2,230.3,230.3 230.5,230.2,230.2 230.6,230.6,230.2	0.0,0.0,0.0 0.0,0.0,0.0 0.0,0.0,0.0 0.0,0.0,	26.0 26.0 26.2 26.2 26.0	100 100 100 100 100	



Each point gives the values of the measurement.



for exporting in a CSV format file.

7.5. DEVICE CONTEXTUAL MENU



Right-click on a UPS icon to open the contextual window

Super-admin	User with Admin role	User with user role	Function		
Delete	Delete		Remove the device from dashboard		
Edit Edit		Edit	Modify name, community, IP, SNMP version		
Browse	Browse	Browse	Open web page		
Alarm table	Alarm table	No	Ack. Events		
History Data	History Data		Measurements log		
Properties	Properties		Summary of device		

7.6. DASHBOARD CONTEXTUAL MENU

Right click on the map or photo



Functions

Super-Admin	per-Admin User Admin		Description		
Add Group	Add Group /		Add a new level of view		
Add device Add device		/	Add device listed in user account		
Мар Мар		/	Change Map		
Entire	Entire	/	View of real time parameters for all devices		
Entire new Page	Entire new Page	/	As above in a separate page		
Save status	Save status	/	Save dashboard presentation		

7.7. ENTIRE VIEW

This page gives the real time measurements for all UPS present in the dashboard. Tables are different according the kind of UPS (Net Vision, EMD, RFC1628 and STATYS)

	Entire X								
ſ	NV6 NV5 RFC1628 STS NV7 UPS NV7 EMD								
	Date	Device	Input Voltage (V)	Output Voltage (V)	Input Frequency (Hz)	Temperature (℃)	Battery Voltage (V)	Output Load (%)	Battery Capacity (%)
	2017-12-13 14:26:59	NV7 MASBC+	231.0,231.0,230.0	230.0,229.0,229.0	50	38	591.2	40,40,39	100
	2017-12-13 14:26:41	NV7 MODGP2	231.0,231.0,231.0	230.0,230.0,230.0	50	27	485.1	0,0,0	100

7.8. LOGS MENU



Calendar: Month by month view of daily event counters History: measurements records table and trends Device Event: log file of all UPS events System Event: log of all events concerning *RV PRO SOFTWARE*.

7.8.1. Calendar

< > today February 2016								
Sun	Mon	Tue	Wed	Thu	Fri	Sat		
31	1	2	3	4	5	6		
7	8	9	10	11 5 9	12 5	13		
14 2 6 1	4	16	17	18	19	20		

Daily report of events counters.

Selecting a day, the <u>Device Log</u> is opened with time window set for this day.

2016/02/15	12	To:	2016/02/15	12
All	٣	Device:	All	
All	٣	Search:		
All	٣			
				Apply
	2016/02/15 All All All	2016/02/15 12 All * All *	Z016/02/15 To: All V All V Search: All	2016/02/15 12 To: 2016/02/15 All v Device: All All v Search: All v

7.8.2. Event Log

Period	From To	Calendar selection
Company	List depends on user rights	All for Admin accounts
Device	List depends on user rights	All for Admin accounts
Severity	Disconnect	
	Config-fail	
	Critical	
	Warning	
	Information	
	Connect	
Ack	All	
	Ack	
	UnAck	
Search		Search the log by specific key word

Additional functions

- Export to SCV format
- Clear all device event logs (only for Admin session)

7.8.3. History Log

Company	List depends on user rights	All for Admin accounts	
Device	List depends on user rights	All for Admin accounts	
End Date	Date of last record to show		
End Time	Time of last record to show		
	Raw data		
	Minute		
Timo unit	Hour	Default sample defined in RV PRO service	
	Day		
	Month		
	Year		
Time window	From 20 min – 2 h. (raw data)	Depende en time unit	
	From 1 day – 14 days (hour)		

Company:	Company	Ŧ	Device:	MODULYS GP 2.0	Ŧ	
End Date:	2016/02/15	12	End Time:	17:43		
Time unit:	Minute	Ŧ	Time window:	30 min	T	
					Apply	

Example: Time unit = Minute / Time window = 30 minutes

Set all fields, and

Apply

to show the records table

30 records in 3 pages (10 records per page are set in System parameters. You can change this from System > System Configure > Column per page)

Numerical Data

Date	Time	Device	IP	Input Voltage (volt)	Output Voltage (volt)	Output Load (%)	UPS Tempera (℃)
2016/02/15	17:42:00	MODULYS GP 2.0	172.23.14.31	231.0,231.0,230.8	230.0,230.0,230.0	0.0,0.0,0.0	26.0
2016/02/15	17:41:07	MODULYS GP 2.0	172.23.14.31	231.0,231.0,230.0	230.0,230.0,230.0	0.0,0.0,0.0	26.0
2016/02/15	17:40:04	MODULYS GP 2.0	172.23.14.31	231.0,230.5,230.0	230.3,230.0,230.0	0.0,0.0,0.0	26.0
2016/02/15	17:39:01	MODULYS GP 2.0	172.23.14.31	231.0,230.8,230.2	230.0,230.0,230.0	0.0,0.0,0.0	26.0
2016/02/15	17:38:08	MODULYS GP 2.0	172.23.14.31	231.0,231.0,230.8	230.4,230.0,230.0	0.0,0.0,0.0	26.0
2016/02/15	17:37:05	MODULYS GP 2.0	172.23.14.31	231.0,231.0,231.0	230.3,230.0,230.0	0.0,0.0,0.0	26.0
2016/02/15	17:36:01	MODULYS GP 2.0	172.23.14.31	231.0,231.0,231.0	230.0,230.0,230.0	0.0,0.0,0.0	26.0
2016/02/15	17:35:08	MODULYS GP 2.0	172.23.14.31	231.4,230.8,230.8	230.0,230.0,230.0	0.0,0.0,0.0	26.0
2016/02/15	17:34:04	MODULYS GP 2.0	172.23.14.31	231.5,230.3,230.7	230.8,230.3,230.2	0.0,0.0,0.0	26.0
2016/02/15	17:33:01	MODULYS GP 2.0	172.23.14.31	231.2,231.0,231.0	230.5,230.0,230.2	0.0,0.0,0.0	26.0
A page 1 of 3		1					

Graphic Data



Last record @16:42

First record @17:11

CSV Export

nv6												
Generated Ti	2016/02/15 1	L8:03:45										
Time from	2016-02-15	Time to	2016-02-15									
Date	Time	Device	IP	Input Voltage	Output Voltage	Output Load	UPS Temperature	Battery Capacity	Battery Voltage	Input Frequency	EMD Temperature	EMD Humidity
15/02/2016	17:11:03	MODULYS GP 2.0	172.23.14.31	232.3 232.2 231.8	230.8 230.7 230.2	0.0 0.0 0.0	26.0	100	486.6	50	0.0	0
15/02/2016	17:10:01	MODULYS GP 2.0	172.23.14.31	232.8 233.0 232.2	230.8 230.5 230.2	0.0 0.0 0.0	26.0	100	486.8	50	0.0	0
15/02/2016	17:09:08	MODULYS GP 2.0	172.23.14.31	232.6 232.4 232.0	231.0 230.4 230.4	0.0 0.0 0.0	26.0	100	486.7	50	0.0	0

7.8.4. System Log

ystem Event Lo	og	
From: 201	6/02/15	12 To: 2016/02/15 12
		Apply
🛃 Clear all	system even	at Log Prev Page Next Page
Sustan Sugar	J	
System Event	LOgs	
Date	Time	Event Description
2016/02/15	17:43:14	User [admin](Admin) clear Device Event logs by manual.
2016/02/15	17:14:27	User admin(Administrator) modify system configuration. (Alarm Audio Severity:0->)
2016/02/15	17:14:27	User admin(Administrator) modify system configuration. (Blanking:enable->disable)
2016/02/15	17:14:20	User admin(Administrator) modify system configuration. (Alarm Audio Severity:0->)
2016/02/15	17:14:20	User admin(Administrator) modify system configuration.(Blanking:disable->enable)
2016/02/15	17:14:06	User admin(Administrator) modify system configuration.(Alarm Audio Severity:0->)
2016/02/15	17:14:06	User admin(Administrator) modify system configuration.(Blanking:enable->disable)
2016/02/15	17:06:20	User admin(Administrator) modify email User1@company.com in company Company.(email:User1@company.com->nicol
2016/02/15	17:06:00	User admin(Administrator) delete email in company Company.(email:admin.it@company.com)
2016/02/15	17:04:46	User admin(Administrator) modify email admin.it@socomec.com in company Company.(email:admin.it@socomec.com->

It presents all action records done in REMOTE VIEW PRO SOFTWARE, for all users

- Login / logout
- System configuration modification

8. UPS EVENTS MANAGEMENT

8.1. New INCOMING UPS EVENT

Action	Interface	Description	Setting
Popup window is opening	On RV Pro service computer	Opens a popup with event description and shortcut to open web page	This function has to be enabled in the Service configuration window
UPS's Flashing icon	If the web page is open	A Flashing icon means that a new event is pre- sent, and needs to be acknowledged	By default all events are notified by RV PRO. An event severity filter can be applied in System page
Events accumulator update	Web page	For each event severity level a counter is updated	The counters are man- aged only during a open session
E-mail notification sending	No need to have an open session	An e-mail is send to a specific recipient accord- ing to events selected or not	SMTP setting in Notifi- cation page. E-mail receiver Configu- ration page: defines the list of receivers, and the list of events

8.2. POPUP WINDOWS

Managed by the *RV PRO Service* (Server or Client) Function not enabled for UPS connected with Net Vision 7



8.3. Event Acknowledgement

The principle of acknowledgement takes into account new UPS events by human action.

After notification via popup or E-mail, you need to open the web interface to acknowledge the new events.

The UPS's icon on the control panel and icons in the tree will continue to flash until the event has been acknowledged..

8.3.1. Alarm table access

Right click on the UPS icon, and select Alarm Table

C	Alarm Table			
	acknowledge Date		Time	Event Description
		2016/02/15	15:45:00	A general fault in the UPS has been detected.
		2016/02/15	15:44:39	Removed: A general fault in the UPS has been detected.
		2016/02/15	15:33:07	A general fault in the UPS has been detected.

Select 'acknowledge' and 'ACK"

 Alarm Table —			
acknowledge ☑	Date	Time	Event Description
	2016/02/15	15:45:00	A general fault in the UPS has been detected.
	2016/02/15	15:44:39	Removed: A general fault in the UPS has been detected.
	2016/02/15	15:33:07	A general fault in the UPS has been detected.

ACK ALL

Those events will be removed from this window after acknowledgement.

'ACK ALL' button acknowledges all alarms in one click.

The UPS icon switches to green after acknowledgement action.

8.3.2. Device Log

The <u>Device Event Log</u> shows all events, acknowledged or not.

From:	2016/02/15		12	To:	2016/02/15	12	
Company:	All			Device:	All		
Severity:	All			Search:			
Ack:	All		v]			
						Apply	
Clear al Device Ever	l device event log nt Logs	Prev P	Next P	age			
Clear al Device Ever Acknowledg	l device event log nt Logs e Date	Prev P	Company	age Device	Severity	_	Event Description
Clear al Device Ever Acknowledg	l device event log nt Logs P Date 2016/02/15	Prev P Time 15:45:00	Company Company	age Device BOX Emulator	Severity warning	A general fault in the UP	Event Description 25 has been detected.

9. INSTALLATION

50Mb disk space free are needed for RV Pro installation.



9.1. SERVER INSTALLATION BY DEFAULT

RemoteView Pro Setup		X
Choose In	stallation Type	
	Client Installs the client configuration.	
	Server Installs the server configuration.	

Case of upgrade version:

- 1. backup the RV Pro configurations.
- 2. stop mysql and RV Pro services
- 3. install the upgrade version.
- 4. reboot the server when finished

9.1.1. Root-Company and Admin account creation:

RemoteViev	v Pro Setup	×
3	First Company Name/Username/Password Setting	
	"First Company Name :	
	*First Company username:	
	"First Company password :	
	*Verify Company password :	
	* required field * Note that field can not support (^ " ' < > \)	
	< Back Next >)

- This information has to be entered when you first start-up the *REMOTE VIEW PRO* web page.
- This account will be used as "Super-admin" for REMOTE VIEW PRO.

🛞 RemoteVi	iew Pro Setup	×
	Installation Progress	
	Configuring Windows features.	
	Installing RemoteView Pro	





This installation type only sets up the RV PRO Client service.

The service starts automatically at the end of installation.

The client service has to be added in *REMOTE VIEW PRO* and connected to all UPS to be monitored by this client.

9.3. Administrator login page

At the end of the installation, the web page with login window is automatically opened.

The login page starts if the www service is running.

Please note: to avoid problems of compatibility, you need to have a browser with versions IE 10, Chrome 22 and Firefox 15 or later.



10. REMOTE VIEW PRO SETUP STEP BY STEP

10.1. Admin account login	
	REMOTE VIEW PRO
Company name set during installation Account Password Verification code given by the alphanu- meric code given below	Company admin Forget Password? Verification
Login	



Root-Company	Мар	Company List					
**	€⊗∕९						
	Company Name	Telephone	Address	FAX	Web	Businėss Tax ID	Description

1. Select Company List at Root level

2. Click on 🛟 icon and complete the form for this company

Root-Company	Map Company List	
**	Company Configuration	*
	Company Name Telephone Address FAX Veb Business Tax ID Description Add Return	

3. Click Add

Once the company is created, USER and DEVICE groups are added to the tree.

⊖ to Root-Company ⊖ to Company	Company Configuration	*
User Group		
Device Group	Company Name Company	
	Telephone	
	Address	
	FAX	
	Web	
	Business Tax ID	
	Description	
		Apply

10.3. USER CREATION

E Soci-Company E Social Company	<u>User Account List</u> € ⊗ ∕ Q				
Device Group	User Name	Telephone	E-mail	Mobile	Status

1.Click on 🛟 icon and complete the form for this user

User Account List Cont	figuration	
Active Company Department	Company	Not Active: the user cannot login to RV PRO
User Name Password Confirm Password Telephone Mobile		Password
E-mail Address		E-mail
User Level	Normal User 🔹	Level: Normal user or Super user with admin
Device List	Select Device	
	· ·	This part is used to link device to this user
	Apply	

2.Click Apply to add this user to the group

E Root-Company	User Account List				
User Group 🔍	€ ⊗∕Q				
	User Nam	e Telephone	E-mail	Mobile	Status
g_borice droup	User 1		rvpro@socomec.com		Active

3.Select the box in the line and click on 🦯 to modify user parameters

User	Account List				
•	3/ 0				
	User Name	Telephone	E-mail	Mobile	Status
	User 1		rvpro@socomec.com		Active

4.Confirm modification with Apply

10.4.1. Add a NET VISION 7 Device Group

Before adding a Net Vision 7 node, make sure that the Remote View Pro Server Control is enabled on the Net Vision 7 to add in Remote View Pro.

NET VISION 7 Remote View Pro Configuration page

Server Control	Enabled
Server IP	192.168.1.1
Server Port	80
GUID	00E0D8FFC190
Password	*

1. Add a Device Group 🛟

Device Group Cor	nfiguration	×
Туре:	NV7 ▼	
Name:		
GUID:		
Password:		
Description:		
	Apply]

2. Select NV7 type

Find NET VISION NODE

- 3. Give a name
- 4. Copy the GUID key from Net Vision 7 page
- 5. Set the same password as in Net Vision 7 page
- 6. Apply to finalize the configuration
- 7. A new "NV" Group is adde
- 8. Select the "NV" group crea

A new "NV" Group is added in Dev	ice group	Device Group
Select the "NV" group create		MV MASTERYS BC+
d NET VISION NODE		
nd NET VISION NODE		
Easy to find device on your network environment	Discovery	

10. Add Net Vision 7 Node, click on Discover .

11. Select the node, and click on Add

NOD	<u>E List</u>				
0	3/				
	NODE NAME	Status	IP Address	MAC Address	Version
	NV7 MAS GP4	information	192.168.1.1	00E0D8FFC191UPS	Net Vision 7 v7.00 b9

12. If EMD present is necessary to add it as a Net Vision 7 Node Add UPS in User account

10.4.2. Add RV PRO service

1. Open the configuration window from the RV PRO service server



2. Click right to open the contextual menu, then choose Configuration

Configuration		X
GUID:	9B30DDEC-A353-4637-8C1B	-2163330130FB
Server IP:	172 . 23 . 27 . 168	
Port:	80]
Password:	•••••	
Polling Rate:	10	(3 ~ 30 Seconds
	Popup Event Notification	
	ОК	Cancel

- 3. Copy the GUID key
- 4. Set a password

Go back to REMOTE VIEW PRO web interface

1. Select Device Group

Root-Company	Device Group List	
User Group		
Bevice Group	Company Name Status Name GUID Description	
		•

2. Add a Device Group 🛟

vice Group Cor	ifiguration	
Туре:	iotc 🔻	
Name:		
GUID:		
Password:		
Description:		
Description.		Apply

- 3. Give a name
- 4. Copy the GUID key from RV PRO Service
- 5. Set the same password as RV PRO Service
- 6. Click on Apply to finalize the configuration

Device Group Co	nfiguration	×
Туре:	[iotc ▼	
Name:	RV PRO Server Service]
GUID:	9B30DDEC-A353-4637-8C1B-2163330130FB]
Password:	•••••	
Description:	Service Running on Server]
	Apply]

Once the *RV PRO Service* has been added, the server will try to connect to the service. If the GUID and password are correct, the service will be running and connected to the server data base

GUID and password are used to encrypt the data send from service to server data base.



In case of remote *RV PRO client,* the process to create the Group is the same. Before adding, you will need to know the password and GUID key

10.4.3. Add a device from the RV Pro service

1. Select the service node

⇔ to Root-Company ⇔ to Company	Device	e List				
User Group	" 🛨 🛛	/				
RV PRO Server Service		Device Name	Status	IP Address	MAC Address	Version

2. Add a Device 🛟

ind Device Single Add Return]			
● SNMP v1 ○ SNMP v2 ○ SNMP	v3			
Name: IP Address:				
Write Community:				
	Use STATYS MIB	Apply		

- 3. Select an adding method:
 - Single add: enter the IP address of the device
 - Segment add: enter a range of IP addresses to find devcies
 - Discovery: only for NET VISION SNMP Card
- 4. Select the right SNMP version
- 5. Enter a device name
- 6. Set the read/write SNMP community (public by default)
- 7. Set RFC1628 if UPS is not using NET VISION

Case of NET VISION discovery

Device Name	IP Address	MAC Address	Version
NV5_00e0d8170db8	192.168.1.1	00e0d8170db8	5.06
NV5_00e0d813a16c	192.168.1.2	00e0d813a16c	5.03
NV6_00e0d814f69a	192.168.1.3	00e0d814f69a	6.21
NV6_00e0d815bf73	192.168.10.1	00e0d815bf73	6.21

8. Choose one of the NET VISION listed, and Add in REMOTE VIEW PRO

If after adding, the NET VISION is not connected, check the device parameters.

REMOTE VIEW PRO automatically sets the server IP address in the SNMP TRAP table of NET VISION.

Dev	ice List				
0	8/				
	Device Name	Status	ID Address	MAC Addrore	Vortion
	Device Maine	Juatus	IF Address	MAC AUULESS	VEISION

Device Status

config-fail: the SNMP table has not been set. Check the read/write community connect: the NET VISION is connected to *RV PRO Service*, and the data is polled.

The event rotator indicates the last events, such as:

- Device config ok
- Device connected

To modify data of this NET VISION / UPS

- Check the box
- Click on

Devi	ice List				
•	3 🖉				
	Device Name	Status	IP Address	MAC Address	Version
	NV6_00e0d814f69a	connect	172.23.14.31	00e0d814f69a	6.21
Devi	ice List				
0	3/				
	Device Name	Status	IP Address	MAC Address	Version
	MODULYS GP 2.0	connect	172.23.14.31	00e0d814f69a	6.21

At this stage, the UPS has been added and a user account created.

Next step: link the UPS to User

10.4.4. Adding a STS

- 1. Select 'single add'
- 2. fill the form with the IP address
- 3. select STATYS MIB FILE
- 4. Add

10.4.5. Adding ATS - STATYS XS

- Select the RV Pro server in the "Device Group" tree view
- Click on e adding a new device

 Ind Device

 Ind Device

 Return

 Easy to find device on your network environment

 Discover
- Click on Discover

RV Pro will discover the STATYS XS in the network where the RV Pro service is running.

• Select the device discovered to add in RV pro SW

	Version		MAC Address	IP Address	Device Name
ATS_00e0d81b5c80 192.168.1.16 00e0d81b5c80 1.08		1.08	00e0d81b5c80	192.168.1.16	FS_00e0d81b5c80

• click on Add

The device is added.

If the device doesn't appear in the list the device has to be added manually, selecting 'Single Add' method.

If the RV Pro shows "Config failed" it means the admin account password doesn't match with the default write password set on the STATYS XS: account "SNMP" - password "admin".

10.4.6. Add UPS and STS in User account

1. Select User Group

Company Co	User	Account List				
		User Name	Telephone	E-mail	Mobile	Status
2 KA KA KA Server Service		User 1		rvpro@socomec.com		Active

2. Select the user and click // to modify user settings

3. Select device from list and move it to Select Device side

Activo					
Company	Company		Active	a	
Department	Company		Company	Company	
User Name	llsor 1		Department		
Dassword	•		User Name	User 1	
Confirm Dassword	-		Password	•	
Telephone			Confirm Password		
Mobile			Telephone		
F-mail	pupro@socomec.com		Mobile		
Addross	Typro@socomec.com		E-mail	rvpro@socomec.com	
Heer Level	Suman Usan		Address		
	Japor o Jor		User Level	Super User	
Device List	Select Device			culture to	
IODULYS GP 2.0	▲ ◆	*	Device List	MODULYS GP 2.0	
	* *	•		•	
		Apply			

The device is added to user

To be able to manage devices by user, you will need to create the control panel (graphical interface)

10.4.7. User Control panel creation

- 1. Select the User in the tree
- 2. Map configuration:
 - Google MAP
 - Baidu MAP
 - Static MAP

⊖ € Root-Company ⊖ @ Company ⊖ Ø User Group	Map Configuration
	Map Address benfeld, 67230 go

Static MAP: jpg / jpeg / png / gif file



3. Submit

4. Once the map is well defined, click right inside the MAP, and 'Save Status'



5. Click right again and 'add device'

ld List						
Device	List					
	Device Name	Status	IP Address	MAC Address	Version	
	MODULYS GP 2.0	connect	172.23.14.31	00e0d814f69a	6.21	
						Add

6. Select the UPS and Add



This page will be the entry point of the user, when logged in with right credentials The first User and first UPS have been added, and the UPS can now be monitored.

10.5. Adding New User or Device

The same steps have to be applied to add Users and Devices. The same device can be shared with several Users.

10.5.1. Adding a new UPS using RFC1628 MIB File

1. Select the right RV Pro Service (Server or Client) in the Device Group

Company					
MODULYS GP 2.0	Device Name	Status	IP Address	MAC Address	Version
E Device Group	MODULYS GP 2.0	connect	172.23.14.31	00e0d814f69a	6.21

3. Complete the form, and select 'Use RFC1628 MIB'

Single Add	▼ Return]	
SNMP v	1 ○ SNMP v2 ○ SNMP	v3	
	Name: IP Address: Read Community: Write Community:	APC Symmetra 2kVA	Apply

4. Click on

Apply



11. E-MAIL NOTIFICATION

11.1. SMTP CONFIGURATION

Notification menu:

Enable		
SMTP Server		
SMTP Port		
Sender Email		
Subject Prefix		
Authentication		
User Name		
Password		
	Apply	

RV PRO needs an authentication account if Receivers are in a different domain, and also to send the license request to SOCOMEC.

11.2. TEST E-MAIL:

	rvpro@socomec.com	RV Pro e-mail Test	lun. 15/02/2016 16:11
Ob	jet : RVPro No	tification Device Event	
	Device Identificatio BOX SIMU from REI Model: SYS Referen http://192.168.1.1	n: MOTE VIEW PRO ce Location: SYS User Loc	
E	vent:		
L	oad supplied by au	tomatic Bypass.	
	Date: 2017/12/13	Time: 18:06:28	

11.3.1. Company selection

E-mail Receiver list

E-mail Receiver List		*
⊕ ⊠ ∕ Q		
	Mail Receiver	Status
Add a new receiver 🛟		
Email Receiver Configuration		×
Mail Receiver Event Device Type INV7_UPS * Devices List	Selected Devices	E-mail address Select NV 6 or 7. RFC1628 or STS
NY MacDas NY MacDas NY MacDas Events List Removed The UPB is operating on balany power The UPB is operating on balany power The UPB is operating on balany power The UPB operating the soft of the origin of the text of the soft of the origin of the text of the soft of the origin of the text of the soft of the origin of the text of the soft of the origin of the text of the soft of the origin of the text of the soft of the origin of the text of the soft of the origin of the text of the soft of the origin of the text of the soft of the origin of the text of the soft of the origin of the text of the soft	Selected Events	Select device The list of event depends on the device selected Selected A general fault in the UPS has been Apply
Receivers example settir	ngs:	
E-mail Receiver List		*
⊕ ⊗ ≠ Q		
	Nail Pocoivor	Ctatur

Mail Receiver	Status
admin.it@company.com	enable
User1@company.com	enable

E-mail received :



12. SYSTEM PARAMETERS

12.1. MENU SYSTEM

System Configuration		
Column Per Page: 25 Loon Blinking: 3 When free volume space is less than: 30GB Auto Logout: 3 Static Map Size fix: 3 Withbout Internet Access: 3 Google Map Enable: 4 Baldu Map Enable: 4 Ignore Event Severity Level: 4 Nore Event/History logs: contains deleted devices: 5 SNMP v1/v2 default Write Community: 9 SNMP v1/v2 default Write Community: 9 Constant Write Community: 9 Constant Write Community: 9 Constant Write Community: 9 Default Write Co	 ✓ delete the oldest logs ✓ delete the oldest logs 	 Number of records per page lcon flashing Spare disk space Magnify or not the photo in the dashboard Enable google or baidu site connection Filter to ignore the Ack. Process. But the popup is still open and events stored in the Device Log file. Public Public for NETVISION by default settings Data polling for NET VISION 7 Set audio alarm
Root Company: <u>SOCOMEC</u> Supervisor Name: <u>admin</u> <u>Apply</u>		

12.2. LICENSE MANAGEMENT

Before requesting the License quotation, be sure that SMTP server and email account are set in Remote View PRO. The email account used to send the license quotation should access to external email accounts (outgoing account / IP address).

12.2.1. License quotation

Before to get the license, please send a quotation request. Once the quotation has been approved, you will receive the license key. License form access: clicking on HELP 2 menu than Register item

Register		×	
License Request:	Silver: up to 200 devices		
Company:	ex: Your company's name		
Name:	ex: Your name		Select your License level
Address:	ex: Company's address		
Zip Code:	ex: 67000		
Country:	ex: France		Fill your data: all fields are needed
UPS Serial Number:	ex: P012547854		
e-mail:	ex: name@company.com		Can be STS serial number
Contact Name:	ex: Contact with SOCOMEC		Vaur amail addreas
Phone Number:	ex: 333884545		
Request License Quote:			
Socomec contact e- mail:	ex: name@company.com		
		QUOTE	Email address of your SOCOMEC contact
· · · · · · ·			
License Key:			
		Apply	

Clicking on QUOTE the request is sent you your SOCOMEC Contact, and you will get an email confirmation in your email box. If the email connection is disabled, the content of the form is reported in a popup window. Copy it and send it manually to get the offer for the licence.

12.2.2. How to get the License:

Your SOCOMEC contact will come back to you for the licence offer process.

12.2.3. How to validate my license:

Once you get the License key copy it in "License Key" field, and Apply. Remote View Pro will unlock the number of device to monitor according your license level. The License is unique for 1 server – Remote View Pro installation, and is not limited in time. The "About" window shown the remaining device number.

12.3. Авоит

KI	MOTE	VIEW	PKO	
Vers	on: 1.0.27.2			_
2015 Lic	All Rights Rese ense Key:	nved		
Ma	ximum Device !	Support: 10		
De	dce can be add	: 7		

13. ADDING RV PRO CLIENT FROM REMOTE COMPUTER

13.1. LOCAL MACHINE SETTINGS

Once the RV Pro Client service is installed, you will need to set the Server IP address.

Co	onfiguration		X
	GUID:	21213FF8-774B-4C43-974F-	DC83CFF6F79E
	Server IP:	I	
	Port:	80	
	Password:	•••••	
	Polling Rate:	10	(3 ~ 30 Seconds)
		Popup Event Notification	
	(ок	Cancel

Copy the GUID, and set a password

13.2. CREATE THE RV PRO SERVICE IN SERVER

- 1. Select Device Group
- 2. Copy the GUID and enter the same password
- 3. Click on Apply

Name:	VM remote Client
GUID:	21213FF8-774B-4C43-974F-DC83CFF6F79E
Password:	•
Description:	VM 7 computer
	Appl

The new Device Group is created, and now devices can be added to be managed by this remote computer.

Root-Company Company Company Solution Solution	«	Devi	Nevice Group List				
RV DRO Server Service			Company Name	Status	Name	GUID	
VM remote Client			Company	connect	RV PRO Server Service	9B30DDEC-A353-4637-8C1B-2163330130FB	
3 V Wremote client			Company	connect	VM remote Client	21213FF8-774B-4C43-974F-DC83CFF6F79E	

The Device Group creation is the same as described above.

The new Device Group has to be created in the new company tree (Company 2), such as:



For this architecture, the Devices cannot be shared with Users from other Company. User 2 sees only devices from Company 2

Root-Company Ompany Ompany Ompany Ompany Output	Device List				
Burger 1	Device Name	Status	IP Address	MAC Address	Version
	NETYS HE	connect 1	172.23.27.10	00e0d811744a	6.21
RV PRO Server Service	User A	ccount List Con	figuration	_	×
Company 2 Company 2 User Group Company 2 User 2 NETYS HE Company 2 Company 2 NETYS HE Company 2 NETYS HE	Co	Active Company Department User Name Password nfirm Password Telephone Mobile E-mail Address User Level	Company 2 User 2 • user2@socomec. Super User	com	
	De	vice List TYS HE	2	elect Device	*
			•		·
					Apply

14. TRAP LIST

TRAP list defines the UPS events managed by *REMOTE VIEW PRO*, sent from UPS with TRAP 3 and 4, including WellKnownAlarmList OID. All events listed in TRAP table are stored in the RV Pro event log. Status or alarms not listed are not stored in RV Pro events log.

14.1. NET VISION 6 MIB FILE

upsAlarmBatteryBad	С	unsAlarmBatteryGeneralAlarm	С
upsAlarmOnBattery	W		W
upsAlarmI owBattery	W		W
upsAlarmDepletedBattery	W		W
upsAlarmTempBad	W		W
upsAlarmInputBad	W		C
upsAlarmOutputBad	W	upsAlarmModule1Alarm	W
	W	upsAlarmModule2Alarm	W
upsAlarmOnBypass		upsAlarmModule3Alarm	W
upsAlarmBypassBad	W	upsAlarmModule4Alarm	W
upsAlarmOutputOffAsBequested	W	upsAlarmModule5Alarm	W
upsAlarmUpsOffAsBequested	W	upsAlarmModule6Alarm	W
upsAlarmChargerEailed	W	upsAlarmExternalAlarm1	W
	W	upsAlarmExternalAlarm2	W
upsAlarmUpsSystemOff	W	upsAlarmExternalAlarm3	W
upsAlarmEanEailure	W	upsAlarmExternalAlarm4	W
upsAlarmEuseEailure	W	upsAlarmEService	C
upsAlarmGeneralFault	W	upsAlarmBedundancyLost	W
upsAlarmDiagnosticTestFailed	W	upsAlarmPeriodicServiceCheck	W
upsAlarmCommunicationLost		upsAlarmAllTransferDisabled	W
upsAlarmAwaitingPower		upsAlarmAutoTransferDisabled	W
upsAlarmShutdownPending	W	upsAlarmBatteryRoom	W
upsAlarmShutdownImminent	W	upsAlarmManualBypass	W
upsAlarmTestInProgress		upsAlarmBatteryDischarged	W
upsAlarmPowerSupplyFault		upsAlarmInsufficientResources	W
upsAlarmAuxMainFail	W	upsAlarmOptionalBoards	W
upsAlarmManualBypassClose	W	upsAlarmRectifierFault	W
upsAlarmShortCircuit	W	upsAlarmBoostFault	W
upsAlarmBatteryChargerFailure	W	upsAlarmInverterFault	W
upsAlarmInverterOverCurrent	W	upsAlarmParallelModuleFault	W
upsAlarmInverterDistorsion	W	upsAlarmGenSetGeneral	W
upsAlarmPrechargeVoltageFail	W	upsAlarmGenSetFault	W
upsAlarmBoostTooLow	W	upsAlarmEmergencyStopActive	W
upsAlarmBoostTooHigh	W	upsAlarmBatteryCircuitOpen	С
upsAlarmBatteryTooHigh	W	upsAlarmFansFailure	W
upsAlarmImproperCondition	W	upsAlarmPhaseRotationFault	W
upsAlarmOverloadTimeout	W	upsAlarmBypassFault	W
upsAlarmControlSystemFailure	С	upsAlarmA63	
upsAlarmDataCorrupted	W	upsAlarmModule7Alarm	W
upsAlarmPllFault	W	upsAlarmModule8Alarm	W
upsAlarmInputGeneralAlarm	W	upsAlarmBatteryTemperature	W
upsAlarmRectifierGeneralAlarm	W	upsAlarmRecRedundancy	W
upsAlarmBoostGeneralAlarm	W	upsAlarmInvRedundancy	W
upsAlarmInverterGeneralAlarm	W		

14.2. RFC 1628

	·		
upsAlarmBatteryBad	С	upsAlarmChargerFailed	С
upsAlarmOnBattery	W	upsAlarmUpsOutputOff	W
upsAlarmLowBattery	W	upsAlarmUpsSystemOff	W
upsAlarmDepletedBattery W		upsAlarmFanFailure	W
upsAlarmTempBad	W	upsAlarmFuseFailure	W
upsAlarmInputBad	W	upsAlarmGeneralFault	W
upsAlarmOutputBad	W	upsAlarmDiagnosticTestFailed	W
upsAlarmOutputOverload	W	upsAlarmCommunicationsLost	
upsAlarmOnBypass	I	upsAlarmAwaitingPower	I
upsAlarmBypassBad	W	upsAlarmShutdownPending	W
upsAlarmOutputOffAsRequested	W	upsAlarmShutdownImminent	W
upsAlarmUpsOffAsRequested	W	upsAlarmTestInProgress	

14.3. NETVISION 7 TRAP LIST

upsTrapImminentStop	Critical	upsTrapPowerRestored	Information
upsTrapOverload	Warning	upsTrapAlarmCancelled	Information
upsTrapRedundancyLost	Warning	upsTrapComEstablished	Information
upsTrapBatteryCircuitOpen	Critical	upsTrapShutdwonCancelled	Information
upsTrapBatteryDischarged	Critical	upsTrapAgentRestarting	Information
upsTrapBatteryLow	Critical	upsTrapEmdTempLow	Critical
upsTrapBatteryAlarm	Warning	upsTrapEmdTempNotLow	Information
upsTrapUpsCriticalAlarm	Critical	upsTrapEmdTempHigh	Critical
upsTrapLoadOFF	Critical	upsTrapEmdTempNotHigh	Information
upsTrapCommunicationLost	Critical	upsTrapEmdHumidityLow	Critical
upsTrapOnBatteryPower	Warning	upsTrapEmdHumidityNotLow	Information
upsTrapBatteryTestfailed	Warning	upsTrapEmdHumidityHigh	Critical
upsTrapTemperatureAlarm	Warning	upsTrapEmdHumidityNotHigh	Information
upsTrapOnBypass	Warning	upsTrapEmdFirstInputActive	Critical
upsTrapUpsPreventiveAlarm	Warning	upsTrapEmdFirstInputRestored	Information
upsTrapShutdownWarning	Warning	upsTrapEmdSecondInputActive	Critical
upsTrapShutdownrequest	Warning	upsTrapEmdSecondInputRestored	Information
upsTrapUpsNormal	Information		

14.4. STS TRAP LIST

stsTrapImminentStop	SEVERE
stsTrapOverload	SEVERE
stsTrapSwitchOnPreferedSource	INFORMATION
stsTrapSwitchOnAlternateSource	WARNING
stsTrapSource1PreferredSource	INFORMATION
stsTrapOutputLoadOFF	SEVERE
stsTrapGeneralAlarm	WARNING
stsTrapAlarmCancelled	INFORMATION

14.5. STATYS XS TRAP LIST

ATS Alarm	WARNING
Source A Voltage Abnormal	WARNING
Source B Voltage Abnormal	WARNING
Source A Frequency Abnormal	WARNING
Source B Frequency Abnormal	WARNING
Output Overload	SEVERE
Unit fault (Working power A abnormal)	SEVERE
Unit fault (Working power B abnormal)	SEVERE
Cabinet over temperature	WARNING
Unit fault (Sensor circuit abnormal)	SEVERE
Unit fault (EEPROM data abnormal)	SEVERE
LCD panel connection abnormal	SEVERE
Overload time out, Output off, Reset needed	SEVERE
Phase difference between resources exceed user defined value, Output off, Reset needed	SEVERE
User defined load pre-alarm	WARNING

15. ICONS DEFINITION

15.1. UPS STATUS

	ICONS	COLOUR	DESCRIPTION	REASON
	Q.	Blinking Blue	Disconnected	The device is no longer connected to network
	Ç.	Blinking Magenta	Config-fail	The SNMP receiver TRAP table has not been updated or bad read/write community
UPS	Ç.	Blinking Red	Critical event	Critical TRAP received
Using NET VISION MIB File		Blinking Yellow	Warning event	Warning TRAP received
		Cyan	Info event	Info TRAP or alarm removed TRAP received
	Ç.	Green	All events have been acknowledged	No more events to be acknowledged (normal)
	Ø	Blinking Blue	Disconnected	The device is no longer connected to network
GENERIC	Ø	Blinking Magenta	Config-fail	The SNMP receiver TRAP table has not been updated or bad read/write community
UPS	Ø	Blinking Red	Critical event	Critical TRAP received
Using RFC1628 (including	Ø	Blinking Yellow	Warning event	Warning TRAP received
NETYS RT)		Cyan	Info event	Info TRAP or alarm removed TRAP received
	Ø	Green	All events have been acknowledged	No more events to acknowledged (normal)

15.2. STS AND STATYS XS STATUS

ICONS	COLOUR	DESCRIPTION	REASON
약 ¥	Blinking Blue	Disconnected	The device is no longer connected to network
약 ¥	Blinking Magenta	Config-fail	The SNMP receiver TRAP table has not been updated or bad read/write community
약 ¥	Blinking Red	Critical event	Critical TRAP received
Ş∔ ₽	Blinking Yellow	Warning event	Warning TRAP received
9	Cyan	Info event	Info TRAP or alarm removed TRAP received
9	Green	All events have been acknowledged	No more events to be acknowledged (normal)

15.3. TREE ICONS

Root-company	Company	User group	User	Group of UPS	
		3	Ø	¢+	One of UPS Disconnected
		6	Ø	(,+	One of UPS Config-fail
			Ø	(,	One of UPS Critical event
1		8	P	(,	One of UPS Warning event
		3		(,-+	One of UPS Info event
		8	Ø	© +	All events have been acknowledged

Socomec: our innovations supporting your energy performance



- Tunisia
- India
- China (x2)

- Poland
 Romania
 Singapore
- Slovenia Spain Switzerland Thailand
- Tunisia Turkey UK USA

HEAD OFFICE

SOCOMEC GROUP

SAS SOCOMEC capital 10 633 100 € R.C.S. Strasbourg B 548 500 149 B.P. 60010 - 1, rue de Westhouse F-67235 Benfeld Cedex Tel. +33 3 88 57 41 41 - Fax +33 3 88 57 78 78 info.scp.isd@socomec.com

www.socomec.com





YOUR DISTRIBUTOR / PARTNER

